Meredith MILL

1) Check before use:

- Take off wristbands, rings and similar!
- power switch (on wall) is turned on
- red lever is closed
- distance of stones is set right (black screw)
- bag is secured on outlet
- fill with grain first, set timer, start motor, then open red lever
- Amp-meter doesn't exceed red mark

2) To stop:

- close red lever
- turn off motor
- turn off power switch (on wall)